

3. PROCESS VARIABLE INPUT - PV

The Process Variable input type should be keyboard programmed by the user according to the codes shown on table 1 (refer to INPUT TYPE parameter " **INLTP** ").

All input types are factory calibrated and no additional calibration is required.

Thermocouples are calibrated to NBS standards. RTD's are calibrated to DIN 43760 ($\alpha=0.00385$).

1. PRESENTATION

N1500G is a universal process indicator which accepts a large variety of input signals and sensors.

A five-digit LED display shows measured value and all programming parameters.

Instrument configuration is achieved from the keyboard, without any hardware change.

The user should read this manual thoroughly before using the instrument. It is a fine electronic device and should be used accordingly for best results.

Some of the features of the basic version are:

- Universal input: Pt100, thermocouples, 4-20mA, 0-50mV and 0-5Vdc
- 24Vdc power supply for remote transmitters excitation
- **Maximum** and **minimum** memory
- **Hold** function
- **Peak** and **hold**
- **Tare**

Options are:

- Process Variable retransmission in 0-20mA or 4-20mA
- RS485 MODBUS RTU serial communication
- Regulated 10Vdc power supply for load cells
- 3rd and 4th alarm relays
- Digital input

Display: Shows process variable (PV) and the programming prompts.

Alarm LEDs 1, 2, 3 and 4: show alarm status.



INDEX key - This key is used to access the programming menu and prompts.



BACK key - This key is used to go back to the previously reached prompt in the menu cycle.



UP / MAX key and **DOWN / MIN** - Used to increase and decrease parameters values, these keys are also used to display maximum and minimum values stored in memory..



Special FUNCTION key - This special function key is used for pre-programmed functions as explained in the SPECIAL FUNCTION KEY section of this manual.

2. SPECIFICATIONS

- Power: 85 to 264Vac, 50/60 Hz switching power supply
- Maximum consumption: 4VA
- Relays: 3A / 250Vac SPST
- All input signals are factory calibrated. Thermocouples are calibrated to NBS standards, RTDs to DIN standards.
- Internal resolution: 19500 levels, display: 12000 levels (-1999 to 9999)
- Sampling rate: 5 measurement per second
- Accuracy: Thermocouples J, K, T and N: 0.25% of full scale $\pm 1^\circ\text{C}$.
Thermocouples E, R, S and B: 0.25% of full scale $\pm 3^\circ\text{C}$.
Pt100: 0.2% of full scale
Current or voltage: 0.2% of full scale
- Warm up time: 15 minutes
- Input impedance: 0-50mV, Pt100 and thermocouples: $>10\text{M}\Omega$
0-5V: $1\text{M}\Omega$
4-20mA: 22Ω
- Pt100 measure: 3-wire circuit, $170\mu\text{A}$ excitation current.
- PV 4-20mA retransmission resolution: 1500 levels, 550Ω max.
- Working conditions: 0 to 55°C , 35 to 85% relative humidity.
- Enclosure: Epoxy coated steel
- Weight: 975g
- Dimension: 310mm x 110mm x 37mm depth

TIPO	CODE	CARACTERÍSTICAS
J		Range: -50 to 760°C (-58 to 1400°F)
K		Range: -90 to 1370°C (-130 to 2498°F)
T		Range: -100 to 400°C (-148 to 752°F)
E		Range: -35 to 720°C (-31 to 1328°F)
N		Range: -90 to 1300°C (-130 to 2372°F)
R		Range: 0 to 1760°C (-32 to 3200°F)
S		Range: 0 to 1760°C (-32 to 3200°F)
B		Range: 150 to 1820°C (302 to 3308°F)
Pt100		Range: -199.9 to 530.0°C (-327.8 to 986.0°F)
Pt100		Range: -200 to 530°C (-328 to 986°F)
4-20mA		Linearizes J. Adjustable range: -110 to 760°C
4-20mA		Linearizes K. Adjustable range.: -150 to 1370°C
4-20mA		Linearizes T. Adjustable range.: -160 to 400°C
4-20mA		Linearizes E. Adjustable range.: -90 to 720°C
4-20mA		Linearizes N. Adjustable range -150 to 1300°C
4-20mA		Linearizes R. Adjustable range 0 to 1760°C
4-20mA		Linearizes S. Adjustable range.: 0 to 1760°C
4-20mA		Linearizes B. Adjustable range.: 100 to 1820°C
4-20mA		Linearizes Pt100. Adj. range.: -200.0 to 530.0°C
4-20mA		Linearizes Pt100. Adj. range.: -200 to 530°C
0-50mV		Linear. Adjustable range.: -1999 to 9999
4-20mA		Linear. Adjustable range.: -1999 to 9999
0 a 10V		Linear. Adjustable range.: -1999 to 9999

Table 1 - Input type codes

4. ALARMS

The indicator features 2 alarm outputs in the basic version and up to 4 alarms outputs as options.

Each alarm has a corresponding LED annunciator in the front panel to show alarm status.

TYPE	PROMPT	ACTION
Disabled	oFF	Alarm is inactive
Sensor Break (input Error)	IErr	Alarm will go ON if sensor breaks, input signal is out of range or Pt100 is shorted.
Low Alarm (Low)	Lo	
High Alarm (High)	Hi	
Diferential Low (diferential Low)	dIFLo	
Diferential High (diferential High)	dIFHi	
Diferential (diferential)	dIF	

Table 2 - Alarm functions

4.1 ALARM FUNCTIONS

The alarms can set to operate in six different functions: Sensor break, Low Alarm, High Alarm, Differential Low, Differential High or Differential (Band). These functions are shown in table 2 and described as follows

4.1.1 Sensor break

The alarm will go ON whenever the sensor breaks or is badly connected.

4.1.2 Low alarm

The alarm relay will go ON whenever the measured value is below the alarm set point.

4.1.3 High alarm

The alarm relay will be ON whenever the measured value is **above** the alarm set point.

4.1.4 Differential (Band)

For differential alarm 2 parameters must be set: Differential **Alarm Reference** value (ALrEF) or alarm setpoint and Alarm Deviation (Band).

For a positive deviation the alarm will switch on whenever the measured value is **out** of the band defined as:

$$(\text{ALrEF} - \text{Deviation}) \text{ and } (\text{ALrEF} + \text{Deviation})$$

For a negative deviation the alarm will be switched on whenever the measured value is **within** the band defined above.

4.1.5 Differential Low

The alarm relay will be ON whenever the measured value is **below** the band defined as:

$$(\text{ALrEF} - \text{Deviation})$$

4.1.6 Differential High

Alarm relay will be ON when the measured value is **above** the band defined as:

$$(\text{ALrEF} + \text{Deviation})$$

4.2 ALARM INITIAL BLOCKING

The initial blocking option inhibits the alarm from being recognized if an alarm condition is present when the controller is first energized. The alarm will actuate only after the occurrence of a non alarm condition followed by a new occurrence for the alarm.

The initial blocking is disabled for the **sensor break** alarm function.

4.3 ALARM TIMER

The alarms can be programmed to have timer functions where the user can set a delayed alarm action, just one pulse in an alarm event, or an oscillator function with sequential pulses.

Table 3 shows these advanced functions. Times T1 and T2 can be programmed from 0 to 6500 seconds (refer to item 8.2). Set 0 (zero) at the T1 and T2 prompt for a normal non-timer alarm operation.

The LEDs alarm annunciators will go ON whenever there is an alarm condition regardless of the present alarm status which may be temporarily off because of timer action.





Advanced Function	T1	T2	ACTION
Normal Operation	0	0	Alarm Output 
Delayed	0	1s to 6500s	Alarm Output 
Pulse	1s to 6500s	0	Alarm Output 
Oscillator	1s to 6500s	1s to 6500s	Alarm Output 

Table 3 - Timer Alarm Functions

5. SPECIAL FUNCTIONS

5.1 MAXIMUM AND MINIMUM

The indicator memorizes the measured maximum and minimum values (peak and valley). These two values are shown by pressing either the **MAX** or **MIN** key. Pressing both keys simultaneously will clear the memory for a new peak and valley detection.

5.2 SPECIAL FUNCTION KEY AND DIGITAL INPUT

The **F** key and the optional digital input can execute special functions according to the user selection.

These functions can be chosen independently to the **F** key or to the digital input. Figure 10 shows how to activate the digital input. A closed contact or a short circuit at terminals 8 and 9 is recognized as activating the digital input.

The special functions for the **F** key and for the digital input are explained as follows.

5.2.1 Hold

The **hold** function freezes the measured value in the display. Each touch at the **F** key or closing the digital input alternates from **hold** to normal mode.

Whenever the indicator is in the **hold** mode a **"HoLd"** message is briefly displayed to show the operator that the displayed value is the frozen value and not the present reading.

5.2.2 Peak Hold

The indicator turns automatically to **Peak Hold** mode whenever the **F** key or the digital input are programmed for **"PHoLd"**

This operation mode makes the indicator display only the maximum reading value from the time the key was pressed of the digital input was activated.

Each activation of the **F** key or digital input triggers a new **Peak Hold** cycle and the display resets with a new peak value.

5.2.3 rESEt (clears maximum and minimum)

This function works the same way as the MAX and MIN keys pressed simultaneously, as explained in the 5.1 section.

If this **"rESEt"** function is programmed, for every touch of the **F** key or activation of the digital input the memory will be cleared and a new cycle of maximum and minimum will start.

5.2.4 AL.oFF - Alarm blocking

This function allows the user to block or inhibit the alarm relays by pressing the **F** key or by activating the digital input. Each touch of the key or activation of the digital input will alternate the function from ON to OFF and vice-versa.

If an alarm situation occurs, the respective alarm status LEDs in the front panel will light regardless of the relay alarm blocking status.

5.2.5 Tare

This function is used to zero the display. The tare residual values is subtracted or added to the total measured value. This functions is generally used with load cells and strain gauges and applies to linear 4-20mA, 0-50mV and 0-5V inputs.

5.3 PROCESS VARIABLE RETRANSMISSION

As an option, the indicator can be supplied with an isolated 0-20mA or 4-20mA analog output for Process Variable (PV) retransmission.

The PV values which define the range of the 0-20mA or 4-20mA retransmission can be programmed by the user in the **high and low indication limits**.

When available, this current output will be always active.

For a voltage output signal an external shunt (calibrated resistor) should be installed at the analog output terminals.

6. INSTALLATION

6.1 PANEL ASSEMBLY

The indicator is composed of two parts: the fixing base and the front part with main circuits. The base must be removed from the front and fixed onto a wall by means of four designed holes as shown in figure 2.




Figure 2 - Mounting the indicator in the panel cut-out.

The front part is only attached to the fixing base after all electrical wire connections are done.

6.2 ELECTRICAL CONNECTIONS

As ligações são realizadas no conector interno do indicador. Devem ser realizadas antes da fixação do corpo principal do indicador à base de fixação.

A disposição dos sinais no conector interno é mostrada a seguir na Figura 3.




Figure 3 - Back panel terminals

6.2.1 Recommendations for Installation

- Input signal wires should be laid out away from power lines and preferably inside grounded conduits.
- Instrument mains should be suitable for this purpose and wires should not be shared with high consumption motors and inductors.
- RC filters (47Ω and 100nF) are highly recommended for valve and contactor coils, etc.

6.2.2 Sensor or input signal connection

É importante que estas ligações sejam bem feitas, com os fios dos sensores ou sinais bem presos aos terminais do painel traseiro. Na necessidade de emendas em termopares, estas devem ser realizadas com cabos de compensação apropriados.

O RTD (Pt100) a ser utilizado é do tipo três fios. Os fios ligados aos terminais 7 e 8 devem ter resistências semelhante (mesma bitola) para evitar erros em função do comprimento do cabo. Se o sensor possuir 4 fios deixar um desconectado junto ao indicador. Para Pt100 a 2 fios, fazer um curto circuito entre os terminais 7 e 8 do indicador, ligando o Pt100 nos terminais 8 e 9.

7. OPERATION

For best results this indicator requires correct setting of parameters as input type (t/c, Pt100, 4-20mA, etc), alarms actuation point, alarm function, etc.

These parameters are divided in five levels or groups of parameters which we will refer to as CYCLES.

Cycle	Access
1- Work	free access
2- Alarms	
3- Functions	
4- Configuration	reserved access
5- Calibration	

Table 4 - Parameters Cycles

The work cycle has free access. All other cycles require a certain combination of key strokes to be accessed. The combination is:

INDEX and BACK keys pressed simultaneously

Within a certain cycle just press INDEX to go to the following parameters. At the end of each cycle the display will go back to the work cycle.

At the desired prompt just press the **MAX** or **MIN** key to change this parameter accordingly.

All changes are recorded in non-volatile memory as we move to next prompt.

After 25 seconds with no key pressed the indicator will return to the measuring cycle (work cycle).

7.1 CYCLE PROTECTION

The values of parameters of a certain cycle can be protected against non-authorized users.

The protected parameters can still be viewed but can not be changed.

To protect a cycle just press the **BACK** and **MAX** keys for 3 seconds at the beginning of the referred cycle. To unlock this cycle just press the same keys again for 3 seconds.

The display will briefly blink confirming that the locking or unlocking of the cycle.

8. PROGRAMMING THE INDICATOR

8.1 WORK CYCLE

This is the first and main cycle. At power up the indicator will display the Process Variable (PV). The alarm setpoints are also displayed at this cycle. To run through this cycle just press the INDEX key.

Whenever an alarm is set with differential function the respective alarm setpoint is blocked (SP.AL1, SP.AL2, ...) and the display shows "diF" to advise the operator that this is a configuration parameter and that the respective deviation value must be programmed at the Alarms Cycle. The "AL.rEF" prompt will be displayed showing the reference value for the alarm with differential function.

TELA	PARAMETER DESCRIPTION
88888	Measure Shows the measured variable. For Pt100 or thermocouples the display will show the absolute temperature value. For 4-20mA, 0-50mV and 0-5V inputs the display shows the values defined in the in.LoL and in.HiL prompts. With the hold function programmed the display shows the frozen variable and alternates with the message "HoLd". Likewise, with Peak Hold function programmed the high limit is displayed with the "P.HoLd" prompt alternately. Should any fault situation occur the indicator will display an error message which can be identified at item 11 of this manual.
AL.rEF	Differential Alarm Reference Value - This prompt is shown only when there is an alarm programmed with differential function.
SP.AL1 SP.AL2 SP.AL3 SP.AL4	Set Points of Alarms 1, 2, 3 and 4 - Defines the operation point of each alarm programmed with "Lo" or "Hi" function. Note: When the alarms are programmed with differential function, the alarm setpoint cannot be changed at this cycle and a "diF" message will be shown. The SP differential (deviation) value is set at the Alarm Cycle.

8.2 ALARM CYCLE

Fu.AL1 Fu.AL2 Fu.AL3 Fu.AL4	Alarm Function - Defines the alarms 1, 2, 3 and 4 function, as defined in item 4.1 oFF : Alarm off iErr : Broken or Shorted Sensor Lo : Low value Hi : High value DiFL : Differential low DiFH : Differential high DiF : Differential
dF.AL1 dF.AL2 dF.AL3 dF.AL4	Differential SP for Alarms 1, 2, 3 and 4 - Defines the deviation value from the alarm setpoint in relation to the Reference Value defined in the "ALdiF" prompt. Note: This value cannot be changed at this cycle for alarms with non-differential function and the "Abs" is then displayed.
HY.AL1 HY.AL2 HY.AL3 HY.AL4	Alarm Hysteresis This is the difference from the measured value to the point where the alarm is turned ON and OFF.
bL.AL1 bL.AL2 bL.AL3 bL.AL4	Alarm Blocking Should any alarm condition occur, each alarm can be disabled when energizing the indicator. Refer to item 4.3.
AL.t1.1 AL.t1.2 AL.t2.1 AL.t2.2 AL.t3.1 AL.t3.2 AL.t4.1 AL.t4.2	Time Alarms The user can set delayed or sequential alarms as shown in table 3 by defining times T1 and T2. To disable this function just set zero for T1 and T2.

FFunc	F KEY FUNCTION - Options are oFF - Key no used. Hold - Hold PV AL.oFF -Alarm disabled rESet - Resets Peak and Valley PHoLd - Peak Hold tArE - Tare zeroing These functions are described in item 5.2.
dIG.In	Digital Input Function - The same function available for the F key: oFF - Hold - AL.oFF - rESet - PHoLd - tArE Refer to item 5.2.
FILtr	Input Digital Filter - Adjustable from 0 to 20, this is used to reduce instability of the measured value. 0 means the filter is off and 20 means maximum filtering. The higher the filter value the lower is the measured value response.
oFSEt	Display Offset - This a value which is added to the PV to offset any measurement deviation or sensor error. The offset is shown directly in the programmed engineering unit. For °F measurements the null reference is at 32 °F.
bAud	Baud Rate - Serial digital communication speed in bps . Programmable: 1200, 2400, 4800, 9600 and 19200 bps.
AdRES	Communication Address - A number which identifies the instrument in a multidrop network.

8.4 CONFIGURATION CYCLE

in.tYP	Input Type - Selects the input signal or sensor type to be connected to the PV terminals. Refer to table 1. Changing this parameter will change all other parameters related to PV and alarms, therefore it should be the first parameter to be set.
dP.PoS	Decimal Point Position - Defines the decimal point position in the displayed value. This applies to linear input types 0 to 50mV, 4 to 20mA and 0 to 5V as selected at the "in.tYP" prompt.
un it	Temperature Unit - Selects °C or °F indication. This prompt is not shown for input types 0 to 50mV, 4 to 20mA and 0 to 5V as selected at the "in.tYP" prompt.
Sroot	Square Root - This prompt is only shown for input types 0 to 50mV, 4 to 20mA and 0 to 5V as selected at the "in.tYP" prompt. Set "YES" and the square root will be applied to the measured value within the limits programmed in "in.LoL" and "in.HiL". The display will show the low limit value should the input signal be below 1% of the range.
in.LoL	Input Low Limit - Sets the low limit for input type 0 to 50mV, 4 to 20mA or 0 to 5V. When the PV Retransmission is used this limit defines the corresponding 4mA (or 0mA) in relation to the input value.
in.HiL	Input High Limit - Sets the high limit for input type 0 to 50mV, 4 to 20mA or 0 to 5V. When the PV Retransmission is used this limit defines the corresponding 20mA in relation to the input value.
SCALE	Scale Factor - Multiplies the displayed value by 10 to increase measured range.
out.tY	Analog Output Type - Selects the analog output type to either 0 to 20mA or 4 to 20mA.

All input types are factory calibrated and field calibration is seldom necessary. Should it be required the calibration should only be done by experienced personnel.

If this cycle is accidentally accessed do not touch the ^ or v keys. Just press the index key and go through all cycles until the display shows the main or operation menu.

in.LoC	Input Low Calibration - Sets the Process Variable low calibration (offset). Several key strokes at ^ or v might be necessary to increment one digit.
in.HiC	Input Hi Calibration - Sets the Process Variable span calibration (gain). Several key strokes at ^ or v might be necessary to increment one digit.
ou.LoC	Analog Output Low Calibration - Sets the analog current output low calibration (offset).
ou.HiC	Analog Output Span Calibration - Sets the analog current output high calibration (span).
CJ Lo	Cold Junction Calibration - Allows the user to adjust the this calibration directly in degrees for achieving best results with thermocouples.
H.tYPE	Hardware Type - This parameters adapts the software to the hardware available and should not be changed by the user. 0 - No options 1 - With alarms 3 and 4 2 - With digital input

9. DIGITAL COMMUNICATION

The indicator can be supplied with an asynchronous RS-485 digital communication interface for master-slave connection to a host computer or SCADA systems.

The indicator works as a slave only and all commands are started by the computer which sends a request to the slave address. The addressed unit sends back the requested reply. Broadcast commands (addressed to all indicator units in a multidrop network) are accepted but no reply is sent back in this case.

9.1 CHARACTERISTICS

RS-485 compatibility with two-wire connection from the host to up to 31 slaves in a multidrop network topology. Up to 247 units can be addressed by the MODBUS RTU protocol.

Maximum network distance: 4,000 feet. Optically isolated signals.
 Selectable baud rate: 1200, 2400, 4800, 9600 or 19200 bps.

Number of data bits: 8, without parity. Stop bits: 1

9.2 RS485 INTERFACE ELECTRICAL CONNECTION

The RS-485 signals are:

D: Bi-direcional data line. \bar{D} : Inverted bi-direcional data line.

⏏ : Ground. To be used in noisy environments for achieving best results.

Two parameter must be properly configured:

Baud rate (**bAud**) and the indicator address (**AdRES**).

10. PROBLEMS WITH THE INDICATOR

Connection errors or improper configuration will result in malfunctioning of the indicator. Carefully revise all cable connections and programming parameters before operating the unit.

Some error messages will help the user identify possible problems.

Message	Possible Problem
UUUUU	Measured value is above the programmed sensor or input signal limit.
NNNNN	Measured value is below the programmed sensor or input signal limit.
-----	Open input. No sensor is connected or the sensor is broken.
Err 1	Pt100 cable resistance is too high or the sensor is badly connected.

Different messages other than the ones above should be reported to the manufacturer. Please inform the serial number if this should occur. the serial number can be viewed at the display by pressing the **BACK** key for about 3 seconds.

The software version of the instrument can be viewed at the time the unit is powered. The instrument might display false error messages when wrongly programmed or when connected to a sensor for which it was not programmed.