

## Introduction

---

The HPS-200 from HandyWave is a ready-to-use short-range wireless connectivity solution for industrial. It provides the most economic and powerful way of cable replacement for the serial communication systems including RS-232, RS-422, and RS-485.

### Features

- Supports DIN-RAIL and Wall Mount
- Supports Bluetooth Serial Port Profile and Generic Access Profile
- No need of external host and software
- Easy of installation and use
- Supports configuration of the local device
- Supports configuration of the remote device via Over-the-Air
- Easy of maintenance
- Supports up to 100 meter (Line of Sight)<sup>1</sup>
- Supports RS-232, RS-422, and RS-485
- Supports Point-to-Point and Point-to-Multipoint Topology

### Specifications

- Standard: Bluetooth Specification Version 1.2 and/or above
- Operation Frequency: 2.4GHz ISM Band
- Transmitted Power: Max 20 / Typical 16dBm (Class 1)
- Received Sensitivity: More than -80dBm
- Power Supply: DC +5 ~ +30V
- Current Consumption: Up to 200mA at DC 5V
- Operation Temperature: -20 ~ 60 °C
- Dimension: 52.5mm (W) x 86.0mm (D) x 58.0mm (H)
- Baud Rate: 1.2, 2.4, 4.8, 9.6, 19.2, 38.4, 57.6, and 115.2Kbps
- Antenna Interface: SMA Female
- Signal Interface: 14 Terminals and screws

### Contents

- HPS-200 2 EA
- Antenna 2 EA
- A Quick Start Guide

---

<sup>1</sup> It can be extended up to 1Km with a high gain antenna.

## Hardware Setup

### Interface

| Items   | Description                 |                |                                | Figure      |
|---------|-----------------------------|----------------|--------------------------------|-------------|
| ANT     | Antenna Port                |                |                                |             |
| OPR/LNK | LED Display                 |                |                                |             |
| RS-232  | Serial Selection Switch for |                |                                |             |
| RS-422  | RS-232,                     |                |                                |             |
| RS-485  | RS-422, and RS-485          |                |                                |             |
| RST     | Configuration Button        |                |                                |             |
| Pin #   | Signal                      | Direction      | Descriptions                   |             |
| 1       | TxD                         | O <sup>1</sup> | TxD for RS-232                 |             |
| 2       | RxD                         | I <sup>2</sup> | RxD for RS-232                 |             |
| 3       | RTS/DTR                     | O              | RTS/DTR for RS-232             |             |
| 4       | CTS/DSR                     | I              | CTS/DSR for RS-232             |             |
| 5       | GND                         | Common         | Signal Ground                  |             |
| 6       | GND                         | Common         | Power Ground                   |             |
| 7       | Power                       | I              | Power Supply                   |             |
| 8       | TX+/TRX+                    | I/O            | TX+: RS-422<br>TRX+: RS-485    |             |
| 9       | TX-/TRX-                    | I/O            | TX-: RS-422<br>TRX-: RS-485    |             |
| 10      | RX+                         | I              | RX+: RS-422                    |             |
| 11      | RX-                         | I              | RX-: RS-422                    |             |
| 12      | GND                         | Common         | Signal Ground                  |             |
| 13      | EoR+                        | O              | End of Resistor <sup>3</sup> + | RS-485 Only |
| 14      | EoR-                        | I              | End of Resistor –              | RS-485 Only |

### Quick Installation Guide

- Step 1: Assemble a provided antenna to the antenna port on the HandyPort.
- Step 2: Select a serial interface using the serial selection switch on the HandyPort.
- Step 3: Make connections using 14 terminals and screws for power and serial interface.
- Step 4: Configure the HandyPort, if necessary.

<sup>1</sup> O: Output

<sup>2</sup> I: Input

<sup>3</sup> End of Resistor: If the HandyPort is required an end of resistor, you can make a loop between EoR+ and EoR-. It is only for RS-485.

## Connection Overview for Power and Serial Interfaces

### Power

| Pin # | Signal | Descriptions                 |
|-------|--------|------------------------------|
| 6     | GND    | Power Ground                 |
| 7     | Power  | Power Supply (DC +5V ~ +30V) |

### RS-232

| Items  | Location |                |                                    | Figure |
|--------|----------|----------------|------------------------------------|--------|
| Switch | RS-232   |                |                                    |        |
| Pin #  | Signal   | Direction      | Remarks                            |        |
| 1      | TxD      | O <sup>1</sup> |                                    |        |
| 2      | RxD      | I <sup>2</sup> |                                    |        |
| 3      | RTS/DTR  | O              | Please see the below. <sup>3</sup> |        |
| 4      | CTS/DSR  | I              |                                    |        |
| 5      | GND      | Common         |                                    |        |

### RS-422

| Items  | Location |           |              | Figure |
|--------|----------|-----------|--------------|--------|
| Switch | RS-422   |           |              |        |
| Pin #  | Signal   | Direction | Remarks      |        |
| 8      | TX+      | Output    |              |        |
| 9      | TX-      | Output    |              |        |
| 10     | RX+      | Input     |              |        |
| 11     | RX-      | Input     |              |        |
| 12     | GND      | Common    | If necessary |        |

### RS-485

| Items  | Location |           |                                    | Figure |
|--------|----------|-----------|------------------------------------|--------|
| Switch | RS-422   |           |                                    |        |
| Pin #  | Signal   | Direction | Remarks                            |        |
| 8      | TRX+     | I/O       |                                    |        |
| 9      | TRX-     | I/O       |                                    |        |
| 12     | GND      | Common    |                                    |        |
| 13     | EoR+     | O         | Please see the below. <sup>4</sup> |        |
| 14     | EoR-     | I         |                                    |        |

<sup>1</sup> O: Output

<sup>2</sup> I: Input

<sup>3</sup> Flow Control (RTS/CTS and/or DTR/DSR): You can use the flow control for RS-232. To use the flow control, you have to set the flow control for the HandyPort and DTE accordingly.

<sup>4</sup> EoR (End of Resistor): If the HandyPort is required an end of resistor, you can make a loop between EoR+ and EoR-. It is only for RS-485.

# Configuration

You can change the configuration of HandyPort using HyperTerminal or similar terminal emulator.

## HyperTerminal Settings

- COM Port Settings: 9600 8-N-1, Flow Control: None (Factory Settings of HandyPort)
- Emulation: VT100

## Switch Location

To configure the HandyPort, the serial selection switch shall be at RS-232.

## Start Configurations

Step 1: Make a RS-232 connection between the PC and HandyPort. And supply power for HandyPort.

Step 2: Open a Hyper Terminal at the PC and set it up.

Step 3: Push the RST button on HandyPort. If you enter the configuration mode successfully, LNK LED will be flashing every second.

Step 4: Hit the <Enter> key, 5 second later.

Step 5: Change the configuration of HandyPort with commands, if necessary.

## Usage Printing

If you are in the configuration mode, type “?<Enter>” for listing commands. If you want to know the usage of specific command, type “?[command]<Enter>”. All commands and parameters are case sensitive. Therefore, you have to use the capital letter for commands and parameters.

## End Configurations

After finishing the configuration, you have to execute a command “X” to apply changes and exit the configuration mode.

## Frequently Used Commands

| Command | Syntax       | Description                      |
|---------|--------------|----------------------------------|
| A       | ABD_ADDR<CR> | Change the remote device address |
| B       | BBR[D]<CR>   | Change the baud rate             |
| M       | MMode<CR>    | Change the connection mode       |
| P       | PPA[D]<CR>   | Change the parity bit            |
| S       | SST[D]<CR>   | Change the stop bits             |
| V       | V            | Display the device information   |

Please refer to the user's manual for more details.