

Tinytag USB Cable User Guide

Instructions for the CAB-0005-USB and CAB-0007-USB Cables.

www.tinytag.info

data collection & retrieval » temperature » humidity » shock » vibration » count » voltage » current



Warnings

- If this equipment is installed or used in a manner not specified by the manufacturer then the protection provided by the equipment may be impaired.
- This equipment should only be interfaced to equipment which is powered by a Safety Extra Low Voltage Supply. The maximum voltage levels are to be 30V rms, 42V peak or 60Vdc and separated from hazardous voltages by double or reinforced insulation. For the United States consider a Safety Extra Low Voltage Supply to be a Class 2 source as defined in the National Electrical Code.

Supported Versions of Windows

This cable will work with Windows Vista, 7, 8, 8.1 or 10 (x86 & x64 versions).

Required Software

It is recommended that you use the latest version of Tinytag Explorer with this cable.

To upgrade to the current version, free of charge, go to our web site here:

www.tinytag.info/support

Once installed, you should go to **Options** and **Communication Options** and make sure the **Use fully automatic com port detection** option is selected.


Installing the Cable

With the current version of Tinytag Explorer installed, plug in the cable (this will start the installation automatically).

You will then see a **Found New Hardware** message next to the PC clock:



When the cable has installed, the message will change to tell you the device is ready to use:



Your cable is now ready to use.

Troubleshooting Connection Problems

If you are having problems connecting to your data loggers please:

- Check that the current version of Tinytag Explorer is installed on your computer (this can be done in the software by clicking on **Help** and **About**).
- Check that the cable is securely connected to the USB port on the computer.
- Check that the automatic communication port detection has been turned on.
- Check that the battery in the logger is not flat.

If you still cannot connect to your data logger, or if you should have any other questions, please contact your supplier for further assistance.

Approvals

Gemini Data Loggers (UK) Ltd. operates a Business Management System which conforms to ISO 9001 and ISO 14001.

Warranty & Disposal

- This product carries a manufacturing defects warranty of 12 months from the date of purchase. Units returned under warranty will be repaired or replaced at the manufacturer's discretion. This warranty does not cover mishandling, modification or battery replacement and is subject to the standard Terms and Conditions of Sale, a copy of which is available on request.
- **The equipment/goods are sold "as is" and with "all faults" (applies in USA). Claims under warranty should be referred to the point of sale.**
- Data loggers, accessories and batteries should be disposed of at organised facilities, where available, in line with local regulations.
- In accordance with the WEEE directive Gemini Data Loggers (UK) Ltd. will take back and dispose of any equipment purchased directly. Equipment not purchased directly should be returned to the point of sale for disposal.



Contact Details:
Tel: +44 1382 443000
Email: info@omni.uk.com

Website: www.omniinstruments.co.uk