

TESTO 318



TestView: Visual Inspection Tool A Flexible tool for inspection of accessible area

Testo 318 - 1 & Testo 318 - 2



Get the inside picture without taking it all apart!

The remarkable Testo 318 series Fiberscopes give you the inside edge on diagnosing hundreds of maintenance and repair problems.

The revolutionary flexible shaft adjusts into almost any position. The comfort grip handle allows one hand operation with all the Testo View controls at your finger tips.

An integrated focus ring ensures smooth continuous operation while focusing. A high powered lens clearly focuses on objects as close as 19 mm while a halogen lamp illuminates dark areas with the simple push of a button.

The high impact ABS housing is ready for field use. The sealed lens and shaft may be immersed in liquids without any problem.

- Fast and complete inspection with mirror accessory
- Can be used for all types of diagnosis
- Good for inspecting hard to reach points
- Quick detection of damaged parts without dismantling
- One hand operation
- Optional 45 degree clip on mirror



Halogen lamp for optimum illumination



One hand operation with light switch and focus ring



Easily check for blocked pipes, vents etc.



Optional, clip on 45 degree mirror makes inspection a snap!

Technical data on testo 318

Number of Pixels	6,000
Field of View	40 Degrees
Minimum focus	19 mm
Operating and storage temperature	-23 to +49°C
Shaft tip Diameter	10mm
Light Source	Halogen lamp (600 fc, 3220K)
Housing	ABS Black
Handle dimensions	152 x 36 x 62 mm
Probe length	
Testo 318 -1	914mm
Testo 318 -2	457mm
Battery Type	2 AA



Important note:-

Although the shaft is filled with thousands of fibres, it can be bent repeatedly to a radius of 203 mm

Important information

- ⇒ Never use on or near live parts
- ⇒ Never use on or near live electrical circuits
- ⇒ Never use in explosive atmospheres
- ⇒ Not intended for medical or veterinary use
- ⇒ Avoid over bending the shaft
- ⇒ Over bending will void the warranty
- ⇒ Do not open the handle for any reason
- ⇒ No user serviceable parts inside
- ⇒ Opening the handle will void warranty
- ⇒ Do not submerge the handle in any liquid
- ⇒ Do not immerse the shaft in any solvent for extended periods of time

Warranty

One year, excludes damaged caused by misuse, accidents or modifications to the product. Warranty is void if the user opens the handle for any reason.