

G2/S075 – 3/4" BSP(F)

Stainless Steel 316 inline Turbine meter with local LCD display.

ATEX certified EEx nL IIC T4 U

EN 50021 / BS EN 60529

EN 50081-1 / EN 50082-1

Intrinsically safe for Class I, II, III, Div 1,
Groups A B C D E F G



Above model shown G2S07109LMA / A209LMS7501a1

The G2 range of turbines were primarily designed to offer both reliability & maximum efficiency for a multitude of applications.

Available in a wide range of material options with sizes ranging from 1/4" to 2". This combined with various different outputs means that the principle of construction ensures this line of products continues to offer a cost effective solution to almost any metering application.

Specification:

Series design	In line turbine flow meter with local/remote ATEX LCD display
Housing material	Stainless Steel 316
Fitting size	3/4" BSP(F) - NPT available on request
Linear Flow range	7.6 to 75.7 litre/min (0.456 to 4.45 m ³ /hr)
Extended Flow range	3.8 to 113 litre/min (0.228 to 6.78 m ³ /hr)
Extended Fluid Velocity	0.2 to 3.7 m/sec
15 point Accuracy *	+/- 0.5% of reading
Linear Accuracy	+/- 2.0% of reading
Extended Accuracy	+/- 5.0% of reading
Repeatability	+/- 0.1%
* up to 15 point calibration can be set using the easy to navigate programmable display, optimum accuracy if using this function is +/- 0.5%	
Pressure rating	103 bar (1500 psi)
Operating temp	- 40°C to 121°C (remote display) - 10°C to 60°C (local display)
Typical K-factor	293.26 pulses per litre
Frequency (linear)	37 - 370 Hz
Maximum Pressure Drop (linear)	7.5 PSI @ 75 litre/min
Recommended Strainer	650 micron
Shipping Weight	1.200 Kg

Wetted parts:

Body	Stainless Steel 316
Journal Bearings	Ceramic Al ² O ³ (98% Alumina)
Shaft	Tungsten Carbide
Rotor & Supports	PVDF (Kynar)
Retaining Rings	Stainless Steel 316

Display:

All G2 local turbines are fitted with IP66 LCD display powered by a long life Lithium cell. The display indicates: batch total's 1 & 2, an accumulative totaliser & rate of flow. The functions of this unit can be toggled on & off. Additional features include password protection, 15 point field calibration, factory reset.

All units can be easily configured to read in either: litre/min, litre/hr, Kg/min, Kg/hr, M³/hr, Gallons/min, USG/min, etc... for more information please contact your local distributor.