



Rutland Windcharger Marine Mounting Kits

Rutland Windcharger Marine Mounting Kits are specifically designed to give a professional finish to installation of Rutland Windchargers on your sailing boat.

Rutland's polished stainless steel kits are convenient and quick to assemble. They are pre-drilled, ready to accept to windcharger. Simply choose the appropriate upright **pole kit** for your Rutland Windcharger model and the solid **stays kit** which fits both types of pole is optional.

Mounting Pole Kits	Rutland 500 Series Pole Kit For 500, 503 & 504 models	Rutland 910 Series Pole Kit For 913 model
Included in the kit	2 x 1.0 m stainless steel tubes Tube joiner & fasteners Deck brackets Guy brackets & fasteners etc * Deck through bolts NOT included	2 x 1.2 m stainless steel tubes Tube joiner & fasteners Deck brackets Guy brackets & fasteners etc. * Deck through bolts NOT included
Net Weight	2.94 Kg.	4.25 Kg.
Packed Weight	3.00 Kg.	4.64 Kg.
Pack Dimension	1010 x 90x 50 mm.	1210 x 100 x 60mm.
Outer Tube Diameter	38 mm. (1.5")	45 mm. (1.75")
Overall Height when assembled	2.0 m.	2.4 m.
Part Number	CA-12/01	CA-12/02



Rutland 913 Windcharger on Mounting Pole Kit with Marine Mounting Stays Kit

Marine Mounting Stays Kit

The stays kit is versatile enough to suit most stern rail mountings and is used to stabilise any of the two pole kits available. The kit includes 2 x 1.2m length stays to cut to size if required with 4 end caps. Hinged clamps to fix to the rail have a 32mm diameter with rubber inserts to absorb any vibration that may occur and to reduce to 25mm. For 22mm rails a 25mm hinged clamp is available on request.

Net Weight: 2.44 Kg. Packed Weight: 3.00 Kg.
Pack Dimensions: 1210 x 100 x 60 mm.

Part No: CA-12/32



Marine Mounting Stays Kit

Making Your Own?

Tube Sections — Optionally available are short sections of the correctly sized stainless steel tube for each Windcharger, drilled ready to accept the Windcharger. These may be adapted to a pole or mounting of your own choice or your local boatbuilder may use one to fix to an arch or mizzen mount bracket.

Note: these section are NOT designed to extend the height of the pole kits. If necessary select a single length of tube from a local supplier to achieve greater height.

Accessory	Omni Part Number
1000mm Tube for Rutland 503	CA-12/15
500mm Tube for Rutland 503	CA-12/16
1200mm Tube for Rutland 913	CA-12/03
600mm Tube for Rutland 913	CA-12/04

Deck Mounting Bracket

This may be selected to facilitate installation of a taller or single length pole.
Part Nos:
503 Deck Brkt: CA-12/23
913 Deck Brkt: CA-12/09



Deck Mounting Bracket