

# PosiTest<sup>®</sup> **DFT** Coating Thickness Gage

*Measures coating  
thickness on metals*

**Two models. . .**

*Ferrous* for STEEL

*Combo* for ALL METALS

*Ideal for . . .*

- Powder Coaters
- Paint Applicators
- Coating Inspectors
- Painting Contractors
- Automotive Refinishers  
and Detailers



simply  
measures

**DeFelsko<sup>®</sup>**  
The Measure of Quality

# PosiTest<sup>®</sup> DFT

## Coating Thickness Gage

### Two Models

#### PosiTest DFT Ferrous

- Measures non-magnetic coatings on steel

#### PosiTest DFT Combo

- Measures both non-magnetic coatings on steel AND non-conductive coatings on aluminum, brass, etc. Automatically recognizes the substrate and takes a measurement.

Bright, high contrast color display with large numerals for superior readability.



Actual Size

#### Features

- Fast, repeatable measurements — 60+ readings per minute
- Ready to measure—no adjustment required for most applications
- Zero or 1 Point Calibration Adjustment for complex applications
- Onscreen averaging for up to 99 readings
- Strong, wear-resistant, ruby-tipped probe
- V-groove in probe for positioning on cylindrical parts
- High contrast color display
- Adjustable display brightness for optimal visibility in any environment
- Auto rotating display with lock to prevent unintended rotations
- Simple, icon based menu
- Handy RESET feature when no zero reference is available
- Mils/microns switchable
- Built-in wrist strap for added convenience and safety
- Two year warranty

Measurement Range	0 – 40 mils	0 – 1000 μm
Accuracy	±(0.1 mils + 3%)	±(2 μm + 3%)



Auto rotating display with rotation lock

#### ALL GAGES COME COMPLETE

with wrist strap, precision plastic shims, hard shell storage case, 2 AAA alkaline batteries, instructions, Long Form Certificate of Calibration traceable to PTB, two year warranty.

**SIZE:** 108 x 43 x 20 mm (4.25" x 1.7" x 0.8")  
**WEIGHT:** 54 g (1.9 oz.) without batteries

Conforms to ISO 2178/2360/2808, ISO 19840, ASTM B244/B499/D7091/E376, BS3900-C5, SSPC-PA2 and others

#### Options

**Pouch with belt clip** protects your PosiTest DFT while keeping it within easy reach

**Coating Thickness Standards** to fulfill both ISO and in-house quality control requirements



  
**Made in U.S.A.**

For pricing or any further information, please contact Omni Instruments Ltd.



Measurement and data acquisition solutions

#### Contact Details:

Tel: +44 845 9000 601  
 Fax: +44 845 9000 602  
 Local Tel: 01382 443000  
 Email: info@omni.uk.com

#### Mailing Address:

Suite E, East Kingsway Business Centre,  
 Mid Craigie Trading Estate, Mid Craigie Road,  
 Dundee, DD4 7RH, UK