

# Ceiling Flush Mounted Light Level Sensor - LL-C-V



#### Features and Benefits

- 0-10Vdc output
- Flush mounted
- 24Vac/dc powered
- Energy saving by dimming light ballast

#### **Technical Overview**

The LL-C-V is a light level transmitter designed for use in the active control of artificial lighting, both to optimise light levels and to achieve maximum energy efficiency.

Using a photo-diode cell to detect light levels the LL-C-V provides a 10-2000 lux range, with a linear 0-10Vdc output signal.

#### **Product Codes**

LL-C-V Internal Ceiling Mounted Light Level Sensor

#### Specification

Sensor reference Photo-diode Accuracy Field of view ±5% across range 360°

Coverage 6 metres max. 10 - 2000 Lux Light range 24Vac/dc Supply Voltage Ambient

Temperature -10 to +40°C

Humidity 90%RH non-condensing Material Flame retardant ABS,

polypropylene

ip30 Protection

Country of Origin UK

Conformity EMC, CE & UKCA Marked

#### **WEEE Directive:**



At the end of the products useful life please dispose as per the local regulations.

Do not dispose of with normal household waste

Do not burn.



For pricing or any further information, please contact Omni Instruments Ltd.



**Contact Details:** Tel: +44 1382 443000 Email: info@omni.uk.com Mailing Address: Unit 1, 14 Nobel Road, Wester Gourdie Industrial Estate, Dundee, DD2 4UH.

Website: www.omniinstruments.co.uk




## Ceiling Flush Mounted Light Level Sensor - LL-C-V


#### **Installation & Connections**

- Avoid direct sunlight entering the sensor.
- Do not site within 1m of forced air heating or ventilation.
- Do not site within 1m of any lighting.
- Do not fix to a vibrating surface.
- 1. Ensure that the ceiling tile is of suitable material to support the weight of the unit and that there is sufficient clearance above the ceiling and cut a ø68mm hole in the ceiling tile.
- 2. Remove the protective cover from the top of the detector to expose the wiring terminals.
- 3. Unscrew the cable relief fitting and pass the wiring cables through the protective cover. Wire at the terminals provided as required and replace the protective cover and tighten the cable strain relief.
- 4. Hold the main body and carefully press the outer ends of the spring clips in towards the body. Push the unit through the mounting hole until the front bezel is flat against the ceiling.
- V Supply voltage 24Vac/dc
- 0V Supply 0V
- 0V Output 0V
- OP 0-10Vdc output



### **Dimensions**





For pricing or any further information, please contact Omni Instruments Ltd.



Contact Details: Tel: +44 1382 443000 Email: info@omni.uk.com Mailing Address: Unit 1, 14 Nobel Road, Wester Gourdie Industrial Estate, Dundee, DD2 4UH.

Website: www.omniinstruments.co.uk